



HOW TO CLEAR DTC CODES


- 1) Following directions for hooking up cables, but instead of starting your vehicle, turn the key to the accessory position where the “Check Engine” light comes on.
- 2) Open your Digimoto software.
- 3) Once in the Digimoto Software, click the Trouble Codes tab.



- 4) To view trouble codes, click Refresh.
- 5) You should now see a list of trouble codes your vehicle is reporting to your scan tool, as seen in the next screen.



6) You will now get this screen, click ok.



7) Your list of DTC codes should again be blank, and DTC count should read 0.

